

Standard Operating Procedure for CMBB Dishwasher

- 1) Choose rack(s) appropriate for the dishes to be washed
- 2) Rinse dirty glassware before loading into dishwasher
- 3) Once dishwasher is loaded, start the dishwasher by pressing the power button. It takes a few seconds to start up but when it does it will indicate the cycle number and ask you to press start. Typically, cycle 4 is used for glassware. It should automatically be on this cycle but if it isn't, press the number four when prompted.

NOTE: the dishwasher should automatically dispense soap and perform an acid rinse, so there should be no need to add soap/acid to the dishwasher.

- 4) Unload dishes and dry them as necessary. Cover openings with foil or plastic wrap before returning them to the cabinet.